

BOUNCE HOUSE GALORE

Manufactured By GBC Enterprises, LLC

Inflatable Waterslide SlipSlide

Limits:

1 Child at a time

No child over 150lbs.



Set Up Instructions

1. Select a dry, flat area, making sure it is large enough to accommodate the entire unit, as well as an additional 5' clearance on all four sides of the unit.
2. Make sure the location you select is near an electrical outlet. If no outlet is available you will need a generator.
3. DO NOT GET THE BLOWER WET (MAY CAUSE ELECTRIC SHOCK)
4. Make sure the location is away from tree branches, bushes, food & beverage tables, power lines, and pets. Clear away all debris that may damage the bottom of the unit
5. When setting up on grassy areas, it is recommended that a tarp be placed under the unit. Do not use this unit on asphalt/concrete
6. Using the attached anchor rings and ground stakes that are provided with each unit, securely stake down the sides and corners.
7. Make sure all electrical plugs are secure in their outlets prior to inflating the unit.
8. Connect the air inflation tube to the fan, using the tie-wrap provided. Make sure any other tubes are sealed and all zippers are zipped.
9. The unit has channels set in place to allow for easy assembly of the water tubing and proper adjustments of the 2 nozzles.
10. Once the unit is completely inflated, check to make sure there are no sagging/collapsing pillars or beams and that all sections of the bounce surface are securely inflated.
11. It is necessary to fully inflate the unit before attempting to install the pvc tubing and nozzles.
12. Once the pvc tubing is in place, the spray nozzles properly adjusted and the water source attached (standard garden hose - not included) you may turn your water source on, allowing the unit to get wet

Deflation and Storage

- 1. Deflation should be done by an adult.**
- 2. Children and objects should be moved away from the bounce house.**
- 3. When done using the unit you must turn off the water supply, remove the pvc tubing and spray nozzles and maintain inflation until the unit is completely dry. Drying times vary depending upon weather conditions.**
- 4. The bouncer must be completely dry BEFORE deflation to prevent any mold growth.**
- 5. Turn off and remove the blower from electrical supply. Release the ties on the deflation tube and the inflation tube. Unzip the zipper.**
- 6. The bouncer will deflate on its own within 5-10 minutes.**
- 7. Fold and Roll your bouncer and secure with straps.**

Storage

- 1. Store your bouncer in a dry area.**
- 2. Do not let the bouncer or blower become exposed to rain.**
- 3. Store blower upright to prevent damage.**

General Care

- 1. Your bouncer may be cleaned using a soft sponge and warm water.**
- 2. The bouncer must be completely dry before it is put away to prevent mold growth.**
- 3. With careful use this bouncer should remain defect free for years. However if the material is snagged or torn it may be patched or sewn using a needle and nylon string. If the mattress is punctured or torn, please use the patches and glue provided to seal the area before use.**

Instructions for Repairing

Repairs should only be performed by an adult. Keep repair kit away from Children.

1. Carefully wipe the area clean with mild soap and warm water.
2. Dry the material completely.
3. Cut a patch so it will overlap the area by at least $\frac{1}{4}$ "
4. Carefully spread a light layer of adhesive onto the patch and the surface of the bouncer.
5. Place the patch over the repair spot and press down firmly.
6. Keep pressure on the patch with a smooth heavy item for 24 hours before inflating.
 - Do not conduct repairs near any source of heat. Adhesive is flammable
 - If ingested contact a physician immediately
 - Conduct repairs in a well ventilated area and avoid prolonged breathing of the vapors as they can be harmful
 - Avoid contact with skin and eyes.



Safety Instructions

- Take your child's safety seriously, those not following safety rules should be asked to leave the slide immediately.
- ADULT SUPPERVISION should be maintained at all times. The slide should not be left unattended while people are using it.
- ONE CHILD on the slide at a time
- Child should slide ON THEIR STOMACH ONLY
- Allow user to completely exit the unit before next user begins
- NO STANDING OR JUMPING ON THIS SLIDE. THIS MAY RESULT IN INJURY
- NO FOOD OR BEVERAGES ON THE SLIDE AT ANY TIME.
- NO SHOES, or other objects should be used on the slide at any time.
- It is recommended that all sliders empty their pockets before using.
- All users should remove eyeglasses, jewelry and any other hard or sharp objects before using
- NO FLIPS, WRESTLING OR ANY OTHER FORMS OF ROUGH HOUSING should be allowed on or near the slide
- DO NOT allow bouncers to run into and/or bounce against the walls or support pillars of the slide
- DO NOT allow any climbing or hanging on any interior or exterior surface of the slide
- DO NOT USE THE SLIDE IN THE RAIN.
- Should the ground stakes become loose during operation, have all bouncers exit the unit and secure all ground stakes before allowing users to resume use.
- DO NOT use the slide in excessive wind (15-20+ mph). Should it become windy during operation, stop all play and deflate completely.
- Ages 3 and up only.
- NO PETS
- The Blower is for adult use only. Children should not be allowed to play near the blower.
- Children should not run on the side of the slide where the blower is located
- Following these simple safety suggestions will ensure you longevity of your bounce house as well as a safe, enjoyable time had by those using it.

WARNING!



Read all instructions and safety notices before setting up bouncer.

Adult Supervision Required AT ALL TIMES.

To Prevent Injury ALL rules must be followed at ALL TIMES

ONE CHILD ON THE SLIDE AT A TIME.

Children should only slide on their stomach

Water should not be anywhere near the blower. Danger of electric shock



DO NOT USE in adverse weather (rain or winds in excess of 15-20+ mph)

Keep children away from the blower and electrical outlets.



General Information for Inflatable Waterslide SlipSlide

- This unit is an impressive 24'x7'x7'
- The mattress, slide surface, and containment walls are made from commercial grade 18oz. (0.55mm) thick PVC.
- The arches and their support beams are constructed from 420D fire rated nylon.
- All seams are double or triple stitched.
- Included with the unit is an ample length of PVC tubing, 2 spray nozzles and a standard garden hose connector.
- Total weight when deflated: 138lbs.

**GBC Enterprises, LLC
4069 Joseph Dr. Ste B1
Waukegan, IL 60087
1-877-354-8294**